LF204 Flamingo Iutorial

Materials used:

Creative Paradise, Inc. mold: LF204 Flamingo Stakes An assortment of COE 90 frits Powder Sifter, line and dot sifter Treative Paradise Inc. Ear Wax Vacuum Glass Separator Spray such as ZYP

Respirator Mask (wear when using FI Powder Frit) Spray your mold with a few coats of ZYP before adding frit.



Use a line and dot sifter to place powdered Black frit in the beak, eyes and legs.



place Salmon Pink Opal powdered frit in the head and belly.



Place fine Petal Pink Opal frit over the body, neck and head of the flamingo covering all of the raised areas in this part of the mold.

Frit color is enhanced to show acemen

Use a powder sifter to sift Cranberry Pink Transparent powdered frit into the feather details, the base of the wing, the tail, neck and top of the head.



Place fine Artichoke Opal frit over the top of the grass.





Use a line and dot sifter to place powdered Pea Pod Opal in the top areas of the grass around the leas.

Place fine Spring Green Trans

frit in the entire grass area, fill

all raised areas of the mold in

this area.



Table I*			
Seg- ment	Rate	Temp	Hold
1	300	1150	45
2	150	1370	20
3	400	1470	10
4	9999	900	60
5	100	800	5

\*Before firing in your kiln, click here to see important firing notes.



Fill the mold cavity with medium grain Clear frit. The small Flamingo should weigh 105 grams and the large Flamingo I20 grams. Fire the project to a full fuse. A suggested firing schedule can be found in table I.



over the black in the legs.

